

# ASSEMBLY INTRUCTIONS Two Door Large Base Cabinet Model Number: UG21001

#### In the event of missing or damaged parts:

PLEASE CALL:949-713-3338 | customersvc@ulti-mategarage.com NOTE: Do Not Call Retailer - Contact Manufacturer Direct For Faster Service.



Ulti-MATE Garage | 30021 Tomas, Rancho Santa Margarita, CA 92688. T: 949-713-3338 | W: www.ulti-mategarage.com

# PARTS LIST

BASE CABINET MODEL: UG21001

In the unlikely event of missing or damaged parts PLEASE CALL: 949-713-3338

#### WEB: www.ulti-mategarage.com TOOLS NEEDED FOR ASSEMBLY Phillips Flat Screw Flat Screw





#### In the unlikely event of missing or damaged parts PLEASE CALL: 949-713-3338

WEB: www.ulti-mategarage.com

#	DESCRIPTION	QTY	IMAGE	#	DESCRIPTION	QTY	IMAGE
aa	Logo	1	UITI-MATE	kk	Hinge	4	A CONTRACTOR
bb	Pull	2	X	11	key	2	NO.
сс	Pull Screw 4*24mm	4		mm	Lock Hardware (Door)	1	a la
dd	Cam	16		nn	Lock Hardware (Top Panel)	1	* •
ee	Metal Dowel	16		00	Screw 4*16mm	28	None of the second s
ff	Wooden Dowel	8		рр	Adjustable Foot	4	
gg	Wall Anchor Screw 4.5*50mm	2	THURSDAY OF	qq	Shelf Clip	4	0
hh	Wall Anchor	2	Child State	rr	Hole Cover	1	
ii	Wall Cleat Grommet	2	6	SS	Touch up Crayon	1	
jj	Screw 5*15mm	8		tt	Screw 3.5*14mm	4	The second second

#### **BEFORE YOU BEGIN**

CAM STYLE FASTENERS ARE USED THROUGHOUT THE ASSEMBLY OF THIS CABINET. ASSEMBLE ALL CAMS AS SHOWN BELOW.



PAGE 4







# CHOOSE AN INSTALLATION OPTION







### Option 1 (4 Feet)

Install 4-feet(pp) and adjust feet cylinder for slightly uneven floor surfaces. Included Wall Cleat(e) used for added cabinet stability. If so, screw Wall Cleat into Wood Studs in wall, which often are 16" apart for preferred installation. Make sure to attach wall cleat level and at correct height to wall, so feet are level on ground. Contact local cabinet professional for installation labor cost when in doubt.

## Option 2 (2 Feet)

Install 2-front feet(pp) and use Included Wall Cleat(e). Screw wall cleat into preferred "Wood Studs" in wall, which are often 16" apart. Make sure to attach wall cleat level and at correct height to wall, so feet are level on ground. Contact local cabinet professional for installation labor cost when in doubt.

# Option 3 (Wall Hanging)

"Cabinet Professional Installation" recommended only. Wall cleat(e) installed to Wood Studs in wall. Greatly reduce weight load in cabinet to estimated 50 lbs. Contact local cabinet professional for installation labor cost when in doubt.

#### STEP 4 Option 1 & Option 2



Two front Feet(**pp**)or Four Feet can be used with your cabinet.if installing feet, do so at this time.



#### If Useing installation Opiton 1

You may want to secure the finished unit onto the wall through the top spanners using wood/drywall screws for added stability. When anchoring to dry wall(with no studs), it is strongly recommended that you limit the weight in the cabinet to under 50 lbs. You may want to test the cabinet strength before loading.

#### STEP 4 Option 2 & Option 3



## NOTE:

When installing wall cleat(e) to dry wall, screw directly into studs or use included WALL ANCHOR(hh). You may want to test the cabinet strength before loading.



## NOTE:

For added stability, screw two additional screws into studs through the top spanner(d) of the cabinet.



# STEP 6



# STEP 7





adjustable, so to ensure Doors hang properly, To learn more about adjusting European hinges, go to YouTube to watch video.

## STEP 9

NOTE: If Doors do not lock fully, refer in manual to page(s) showing assembling "Lock Hardware", and or, hinges require adjustment. If you do not want to adjust hinges, with Left Hand push both doors inward while turning key with Right Hand.



Thank you for your purchase of our award-winning products and visit us at: www.ulti-mategarage.com